

"D2008 VALVE ON VTL"

LIST OF CONTENTS

	<u>PAGE</u>
Section I <u>General Description of Tracing System</u>	
Hydraulic Supply Unit	1
Tracer valve	2
Hydraulic motor drives	3
Section II <u>Tracing Valve Operating Theory</u>	4
Section III <u>How to Operate the Tracer System</u>	6
Section IV <u>How to set up for Cutting</u>	9
Section V <u>Tracer Valve Service Procedures</u>	12
1. Removal of side cover plates	12
2. Balancing of axis spools	12
3. Stylus diaphragm replacement	15
4. Steering motor drive belt replacement	16
Section VI <u>General Maintenance</u>	19
Section VII <u>Trouble-Shooting Chart</u>	21

OPERATING AND MAINTENANCE INSTRUCTIONS

MIMIK DYNATRACE 360° Tracing System

SECTION I

GENERAL DESCRIPTION OF TRACING SYSTEM:

The MIMIK Dynatrace 360° Tracing System is designed for tracing two-dimensional contours under full control of the tracer valve. When the tracing stylus is guided onto a template the tracer valve will automatically supply oil to two hydraulic drives in accordance with the template contour. These drives control rotation of the horizontal (saddle) and vertical (ram) feed screws so that the cutting tool follows a path identical to the template contour.

The tracer valve is mounted in a fixed position on the cross-rail, and adjustment is provided to facilitate job setups of varying size and shape.

The template is mounted to the vertical ram, and hence moves in unison with the cutting tool. While this requires that the template be reversed relative to the workpiece, the template itself is a true 1:1 duplication of the desired workpiece contour.

Fig. 1 is a schematic drawing of the hydraulic system. Its main components and their functions are described below:

Hydraulic Supply Unit (See figs. 2 & 3)

This consists of an oil reservoir, oil filters, and two hydraulic pumps (one supplies the two hydraulic drives and the other supplies the steering control in the tracer valve). Mounted on the supply unit are an electrical control panel and a vacuum pump to handle drain oil from the tracer valve.

Refer to Section VI for oil and filter specifications

Tracer Valve

The tracer valve controls the amount and direction of oil flow to the hydraulic drives on the x and y axes. This is accomplished by deflection of the stylus, which is guided around the template by the steering control mechanism in the tracer valve.

Fig. 4 shows the location of the various controls on the tracer valve. These controls function as follows:-

a) Feed Rate Control

Allows operator to set desired feed rate for tracing. This is then maintained automatically over any contour, but may be varied manually during the cut, if desired. Note that this control only affects feed rate while tracing, not while steering manually.

The numbered scale above the control knob is not graduated in distance/time values. It merely assists in returning the setting to a previous value.

b) Feed Direction Selector

Axial movement of this control selects feed direction for tracing either clockwise or counter-clockwise around a contour.

c) Automatic Steering Selector

Allows selection of automatic or manual steering by engaging or disengaging the steering control mechanism. Manual steering is effected by grasping the stylus and deflecting it in the direction of desired feed movement.

The tracer can be manually steered whether the steering selector is set to Manual or Automatic. Manual selection is recommended, however, as stylus deflection force is much lighter and the normal oscillating motion of the stylus is absent.

When steering manually, rate of feed is controllable only by the amount of stylus deflection.

CROSSFEED MOTOR

LONGITUDINAL FEED MOTOR






FIG. 1



56
C.N. #

Rev.	DATE





FIG. 3

ARRANGED IN VALVE
(SEE SIDE VIEW)

FEED DIRECTION SELECTOR

RIGHT COVER PLATE

STEERING MOUNTING
MOUNTING SCREWS

TOP PLATE

FEED RATE CONTROL

AUTOMATIC FEEDING
SELECTOR

LEFT COVER PLATE

TOP VIEW

VERTICAL AXIS
SPOOL (WEIGHT)

CONTROL VALVE (SEE FIG. 3)
VALVE (SEE FIG. 3)
(DIMENSIONS FROM FIG. 3)

VERTICAL AXIS
SPOOL

STEERING BRAS
SPRING

STEERING VALVE

STYLUS COLLET

HORIZ. AXIS
SPOOL

FEED DIRECTION SELECTOR
(D-2004 VALVE)

FEED RATE
CONTROL

STEERING ENGAGEMENT
RING

STYLUS STEM

D-2004 AUTOMATIC FEEDER VALVE (HORIZONTAL MOUNTING)

FIG 4


Hydraulic Motor Drives

Each drive assembly, as shown in Fig. 5, consists of a hydraulic motor controlled directly by the tracer valve, a worm gear reduction box, and an electric clutch to allow disengagement from the machine's feed screws. The clutch output shaft is connected to the feed screw by an Oldham coupling, which ensures positive drive without backlash, and compensates for slight misalignment.


Rotation of the hydraulic motor in either direction is transferred through the worm gear box and thence through the electric clutch to the feed screw. The final drive of the worm gear box is equipped with a graduated dial to indicate rotation.

The electric clutch is controllable through a pendant-mounted push-button switch, and is interconnected to the machine's rapid traverse control so that engagement of rapid traverse automatically disengages the clutch.

NOTE: A 2-speed spur gear box can be added as illustrated below to increase feed rate range where necessary on large machines or for materials having high or low machineability ratings.



GEAR-REDUCED HYDRAULIC MOTOR DRIVE ASSEMBLY




- 1) STEERING VALVE BODY
- 2) STEERING VALVE BODY
- 3) STEERING VALVE BODY
- 4) GEAR PLATE
- 5) RETAINER
- 6) FEED RATE CONTROL
- 7) FEED RATE CONTROL
- 8) FEED RATE CONTROL
- 9) STEERING MOTOR
- 10) STEERING MOTOR
- 11) STEERING MOTOR
- 12) STEERING MOTOR
- 13) STEERING MOTOR
- 14) STEERING MOTOR
- 15) STEERING MOTOR
- 16) STEERING MOTOR
- 17) STEERING MOTOR
- 18) STEERING MOTOR
- 19) STEERING MOTOR
- 20) STEERING MOTOR
- 21) STEERING MOTOR
- 22) STEERING MOTOR
- 23) STEERING MOTOR
- 24) STEERING MOTOR
- 25) STEERING MOTOR

- 18) STEERING MOTOR
- 19) STEERING MOTOR
- 20) STEERING MOTOR
- 21) STEERING MOTOR
- 22) STEERING MOTOR
- 23) STEERING MOTOR
- 24) STEERING MOTOR
- 25) STEERING MOTOR
- 26) STEERING MOTOR
- 27) STEERING MOTOR
- 28) STEERING MOTOR
- 29) STEERING MOTOR
- 30) STEERING MOTOR
- 31) STEERING MOTOR
- 32) STEERING MOTOR
- 33) STEERING MOTOR
- 34) STEERING MOTOR
- 35) STEERING MOTOR
- 36) STEERING MOTOR
- 37) STEERING MOTOR
- 38) STEERING MOTOR
- 39) STEERING MOTOR
- 40) STEERING MOTOR
- 41) STEERING MOTOR
- 42) STEERING MOTOR

**D-2008 AUTOMATIC 360°
TRACER VALVE
(VERTICAL MOUNTING)**

FIG. 6



*D-2008 VALVE ONLY



AUTOMATIC STEERING - TEMPLATE PARALLEL TO ONE MACHINE AXIS

FIG. 7

STEERING VALVE SPOOL
MOVING NEUTRAL WHILE
TURNING TEMPLATE CORNER



AUTOMATIC STEERING - TEMPLATE AT ANGLE TO MACHINE AXES

FIG. 7A

SECTION II

Tracer Valve Operating Theory

Note: Explanatory drawings (Figs. 6, 7 and 7A) show a vertically mounted D-2008 valve. The horizontally mounted D-2024 valve operates in the same manner, with the vertical axis spool being equivalent to the y axis spool noted on these drawings.

The MIMIK Automatic 360° tracer valve consists basically of the two 4-way hydraulic servo valves arranged at 90° to one another, each controlling the rate and direction of oil flow to one of the machine's two hydraulic drives. Actuation of the spools in these two valves results from deflection of the stylus which is held in a steel diaphragm to allow universal pivoting.

In this respect the valve is similar to a manually operated pencil-trace valve, where the operator pushes the stylus in whatever direction he wishes the stylus and cutter to move relative to template and workpiece.

In the Automatic 360° valve, however, the operator is replaced by a third servo valve which controls rate and direction of oil flow to a hydraulic steering motor. Changes in the template contour are sensed by the stylus, and cause the steering motor to move a bias spring around the stylus stem. This bias, or push, applied to the stylus is equivalent to an operator's manual push, but is much more uniform and is completely automatic.

Figs. 7 and 7A further illustrate the action of the system at a change in contour on the template.

SECTION II

Tracer Valve Operating Theory

Note: Explanatory drawings (Figs. 6, 7 and 7A) show a vertically mounted D-2008 valve. The horizontally mounted D-2024 valve operates in the same manner, with the vertical axis spool being equivalent to the y axis spool noted on these drawings.

The MIMIK Automatic 360° tracer valve consists basically of the two 4-way hydraulic servo valves arranged at 90° to one another, each controlling the rate and direction of oil flow to one of the machine's two hydraulic drives. Actuation of the spools in these two valves results from deflection of the stylus which is held in a steel diaphragm to allow universal pivoting.

In this respect the valve is similar to a manually operated pencil-trace valve, where the operator pushes the stylus in whatever direction he wishes the stylus and cutter to move relative to template and workpiece.

In the Automatic 360° valve, however, the operator is replaced by a third servo valve which controls rate and direction of oil flow to a hydraulic steering motor. Changes in the template contour are sensed by the stylus, and cause the steering motor to move a bias spring around the stylus stem. This bias, or push, applied to the stylus is equivalent to an operator's manual push, but is much more uniform and is completely automatic.

Figs. 7 and 7A further illustrate the action of the system at a change in contour on the template.

In Fig. 7 the stylus is against a template edge parallel to the machine axis. The bias angle is proportional to the rate of feed, and has been established by the feed rate control setting. The steering spool is in neutral, so no oil is being ported to the steering motor, and the bias spring is therefore stationary. The spring is exerting a pull on the stylus which deflects it in the x axis only, deflection in the y axis being prevented by the template. This x-axis deflection positions the x spool to produce machine movement parallel to the template edge.

On reaching the outside corner shown in Fig. 7A, the bias spring deflects the stylus in the y, as well as the x, axis, producing a corresponding movement along both machine axes. The slight change in deflection resulting from the contour change moves the steering spool upward. Oil is thus ported to the steering motor and the bias spring rotates about the stylus until reaching the pre-set bias angle. Reduced stylus deflection due to resistance of the template edge then returns the steering spool to neutral.

On reaching an inside corner (not illustrated) stylus deflection is decreased by the newly-presented template edge. The steering spool is moved downward, and the bias spring thus rotates in the opposite direction until reaching the pre-set bias angle. X and y spools are simultaneously positioned to produce machine movement parallel to the template edge.

On curved template contours, the above actions are continuous, the steering valve always seeking to maintain a constant bias angle and thus a constant feed rate.

When the stylus is not against a template edge, it maintains a slightly deflected position which lowers the steering spool below neutral and produces a continuous rotation of the bias spring. X and y spools are thus being continuously repositioned, and the machine members oscillate in a circular pattern. A gradual creep in one direction will occur if the x and y spools are not balanced to suit the machine. (See Section V - 2).

SECTION III

14

HOW TO OPERATE THE TRACER SYSTEM

Operation of the MIMIK Automatic 360° tracer system is extremely simple and requires a minimum of operator training.

This section outlines the procedure necessary to start up the unit, adjust the feed rate, etc.

The procedure for setting up the unit to cut parts is outlined in Section IV.

1. Before starting the pumps, check the oil level gage on the oil reservoir to make sure the oil level is approximately half way up the glass.
2. Check the oiler bottle for the vacuum pump to make sure it contains approximately 1" of oil.
3. To start the pumps, turn the disconnect switch on the electrical control cabinet to 'ON' then press the start button. Check pressure gages and set pumps to give dead-head (no flow) readings as follows:

Steering circuit - 200 psi (feed along straight portion of template)

Feed circuit - 250 psi (Select manual steering and hold in fixed position on template).

Check vacuum pump oiler bottle for adequate oil level with some froth on top. This indicates that vacuum pump is receiving lubrication.

4. Clear the system of any accumulated air by running the ram and saddle back and forth a few times. To do this, turn the automatic steering selector to 'Manual', switch on one axis feed clutch, and deflect the stylus manually. Repeat on the other axis. (Note that electrical panel contains individual switches for each clutch, while remote switch controls both clutches). It is not necessary to run either member to the full end of its stroke.

5. The template may be rough-positioned by means of the machine's rapid traverse controls, which should be interconnected to automatically disengage the tracer drive clutches when engaged. Care must be taken to avoid running the template against the tracing stylus when in rapid traverse.

15

6. There are two ways to start the stylus feeding automatically along the template. In both cases the feed direction selector knob should first be set to the desired direction, feed rate should be set at mid-range, and the automatic steering selector should be set to 'Automatic'.

a) With both drive clutches engaged, steer the stylus manually onto the template in the desired direction of feed. This will establish the steering bias spring at approximately the correct angle, so that when the stylus is released, automatic feed will continue.

b) With both drive clutches disengaged, move the machine ram or saddle manually to advance template toward stylus. The stylus will be oscillating while the template is approaching it. Carefully bring the template against the stylus until stylus oscillation ceases. Do not advance template past this point. Engage drive clutch controlling same axis as template has been moved in to check that template stays against stylus. (If stylus begins to oscillate, repeat previous step.) When both clutches are engaged, stylus should feed along template automatically.

7. Feed direction can be reversed while feeding along the template, but the stylus should be steered manually during the direction change to ensure that it does not oscillate off the template.

8. Set the feed rate to the desired value by turning the feed rate control knob. It may also be necessary or desirable to shift the spur gear boxes into either the high or low ratio, depending upon the feed rate desired.

When taking heavy cuts at low feed rates, the gear boxes should be shifted to the low speed position, and the feed rate adjusted to suit, rather than using the high speed ratio and trimming down the feed rate, as this provides more power for cutting.

9. To stop the tracer at any desired point on the template, disengage one or both clutches, or turn the automatic feed selector to 'Manual'. (The stylus may then require manual assistance to start following the template when re-set to 'Automatic'.)
10. There are two methods of removing the stylus from the template:
 - a) Steer the stylus manually until clear of the template. Oscillation can be stopped by disengaging both clutches or by setting the automatic steering selector to 'Manual'.
 - b) Engage rapid traverse on machine, taking care that template does not strike stylus and tool does not strike workpiece.

(17)

SECTION IV

HOW TO SET UP FOR CUTTING

1. Start hydraulic system and leave running during setup to bring oil to proper temperature. Disengage tracer drive clutches and set automatic feed selector to 'Manual'.
2. Insert a stylus of proper diameter and shape in the stylus collet of the tracer valve.

Where the workpiece contour allows a conventional single-point tool, the stylus contact edge should have the same included angle and nose radius as the tool. Depth of cut adjustments are then taken by adjusting the valve position in either or both axes.

Where the contour involves opposing slopes, either a button or a fishtail-type tool must be used, and the stylus must be either round or fishtail in section. In either case the finish-cut stylus should have the same radius as the tool tip.

Since a valve position adjustment would increase depth of cut on one workpiece slope and decrease it on an opposing slope, cut adjustments must be taken by changing the radius of the stylus. Identical tool and stylus radii are used for the finish cut, while for rough cuts the stylus radius is increased by the amount of workpiece stock to be left on.

Two types of round stylus are shown in figures 8 and 9. A stepped stylus with several diameters is also convenient for roughing, or interchangeable sleeves can be used when the stylus section is not circular. The breakable type stylus will prevent damage if the template is accidentally run into the stylus under rapid traverse.

3. Select proper cutting tool and clamp in toolholder. (Note that tool and stylus contact edges are 180° apart).
4. Using manual machine controls, advance the cutting tool within 1/8" of a reference point on the workpiece.

- 5. Install template so it bears approximately the same relation to the stylus as the workpiece does to the tool.

Note: The tracer valve is mounted stationary and the template moves with the machine ram. With this arrangement the templates are made as for any conventional tracing system. However, before installing the template it must be turned end for end and top for bottom relative to the workpiece.

- 6. Check and adjust template for parallelism as follows:
 - a) Manually move ram up and/or saddle sideways to clear stylus and tool.
 - b) Mount dial indicator on tracer valve or convenient fixed surface and set pointer against straight section of template.
 - c) Feed ram (or saddle) manually and check for parallelism.
 - d) Pivot template to proper alignment, lock in position, and recheck with indicator.

Return ram and/or saddle to original position so tool is 1/8" from workpiece. Adjust valve if necessary to maintain same relationship.

- 7. Pick up reference points on face and diameter of workpiece as follows:
 - a) Reference point on face:
 - Adjust valve upward until stylus almost touches horizontal edge of template.
 - Engage vertical drive clutch and steer stylus manually onto template or move template against stylus with machine handwheel. (See para. 6(b) of Section III).
 - Adjust valve downward. Template and tool will feed downward since vertical tracer feed is engaged. Continue until tool is .005" from reference face of workpiece.

- Use manual machine feed to position tool to approximate horizontal location for next reference point.


b) Reference point on diameter:

- Disengage vertical drive clutch and adjust valve horizontally until stylus almost touches vertical edge of template.
- Bring template against stylus as in (a) above.
- Adjust valve horizontally until tool is .005" from reference diameter of workpiece.
- Position template so stylus is near starting point, using either machine feed or manual valve steering.
- Tool and stylus are now in proper relationship and ready for cutting.

8. Adjust valve position or stylus diameter for desired depth of cut.
9. Start machine spindle, set feed direction selector on valve to desired position, engage drive clutches, and manually steer stylus onto run-on portion of template with auto steering selector set to 'Automatic'.
10. At end of cut ram and saddle can be repositioned for next cut by using machine's rapid traverse controls, by manually steering the stylus, or by feeding under tracer control along an enclosed template, with tracer feed rate advanced during the non-cutting portion.
11. All finish cuts should be taken in the same direction, although rough cuts may be taken in alternate directions if tool geometry permits.
12. Between cuts the valve position or stylus diameter must be adjusted for depth of cut, and returned to original setting for the next workpiece.

REV.	DATE	PARTICULAR
(A)	2467	TEXT


20



END OF STYLUS PROTRUDING FROM VALVE COLLET MUST
 DUPLICATE CUTTER SHAPE.
 ROUGHING STYLUS TO BE LARGER IN DIAMETER THAN
 CUTTER (REFER TO INSTRUCTION).
 NORMAL STYLUS-CUTTER RELATIONSHIP FOR FINISH CUTS IS 1 TO 1.
 FOR EXTREME ACCURACY STYLUS MUST BE ESTABLISHED BY TRIAL.

FIG. 8

21



NOTE
TUBE IS HARDENED TO PERMIT BREAKING
BUT NO BENDING

FIG. 9